

TECNA

 **DIRECT.com**

Industrial Resistance Welders and Tool Balancers

MANUAL: Rotary Insulating Device

Option: RI

PURCHASE YOUR TECNA WELDERS and TOOL BALANCERS!

TECNADirect.com is a Stocking Importer and Master Distributor of TECNA Pedestal Welders, Portable Spot Welding Guns, Bench Welders, Tool Balancers and Accessories.

www.TECNADirect.com

TECNADirect.com is powered by Weld Systems Integrators, Inc., manufacturer of rugged, innovative, high-quality resistance welding equipment and machinery.

For more information on Weld Systems Integrators visit www.wsiweld.com.




 **WELD
SYSTEMS
INTEGRATORS, INC.**
RESISTANCE WELDING. SOLVED.

844-44-TECNA

www.TECNADirect.com • sales@tecnadirect.com

ISTRUZIONI PER L'USO DEL BILANCIATORE | BALANCER INSTRUCTIONS MANUAL
INSTRUCTIONS POUR L'UTILISATION DE L'ÉQUILIBREUR | MANUAL DE USO DEL EQUILIBRADOR
BETRIEBSANLEITUNG DES FEDERZUGS | GEBRUIKSAANWIJZING VOOR DE BALANCER
BALANSEBLOKKENS BRUKERVEILEDNING | BRUKSANVISNING FÖR BALANSBLOCK



OPZIONE "RI", sospensione rotante isolata

Permette di isolare elettricamente il carico appeso al bilanciatore, per esempio in caso di sospensione di saldatrici, e/o di ruotare liberamente l'utensile appeso senza torcere la fune (A).

ATTENZIONE: rispettare sempre le norme di sicurezza relative all'uso di apparecchiature elettriche.
Installazione: infilare il moschettone (B) nel perno (C) della sospensione rotante. Inserire la redancia della fune (A) nel perno (D); inserire la copiglia (E) e deformarla.

OPTION "RI", insulated rotary suspension

Permits to electrically insulate the load hung on the balancer, e.g. in the case of suspension of welding devices and/or turn the hanging tool freely without twisting the cable (A).

ATTENTION: always comply with the safety regulations relative to the electrical equipment.
Installation: insert the snap-hook (B) into the pin (C) of the rotary suspension. Insert the cable thimble (A) into the pin (D); insert the split-pin (E) and deform it.

OPTION "RI", suspension tournante isolée

Permet d'isoler électriquement la charge accrochée à l'équilibreur, par exemple en cas de suspension des soudeuses, et/ou de tourner librement l'outil accroché sans tordre le câble (A).


ATTENTION: respecter toujours les normes de sécurité relatives à l'utilisation d'appareils électriques.
Installation: enfilez le mousqueton (B) dans l'axe (C) de la suspension tournante. Introduisez la cosse du câble (A) dans l'axe (D); introduisez la goupille (E) et la déformez.

OPCIÓN "RI", suspensión giratoria aislada

Permite aislar eléctricamente la carga suspendida en el equilibrador y/o girar libremente la herramienta suspendida sin torcer el cable (A).

ATENCIÓN: Respete siempre las normas de seguridad para el uso de aparatos eléctricos.
Instalación: Introduzca el mosquetón (B) en el perno (C) de la suspensión giratoria; introduzca el guardacabo del cable (A) en el perno (D); introduzca la claveta (E) y déformela.

Diverse inventory with immediate shipping and unmatched customer service.



Weld Systems Integrators (WSI) | Resistance Welding. Solved.

Weld Systems Integrators is a **MANUFACTURER, STOCKING IMPORTER** and **MASTER DISTRIBUTOR** of rugged, innovative, high-quality resistance welding equipment and machinery, and integrator of robotic resistance and MIG welding cells. We also stock resistance welding accessories, parts and supplies, and we support our resistance welding equipment with strong service, training, welding lab testing and contract engineering capabilities.

We work with trusted affiliates and partners to provide the most advanced resistance welding machinery and supplies. We keep a large, diverse inventory of TECNA resistance welder, tool balancers, accessories and instruments **IN-STOCK** at our Warrensville Heights, OHIO location for quick shipment and delivery.

WSI is proud to be a Sustaining Member of the American Welding Society (AWS), the Resistance Welding Manufacturing Alliance (RWMA), as well as WEMCO, an Association of Welding Equipment Manufacturers.



TECNA



Industrial Resistance Welders and Tool Balancers

844-44-TECNA

www.TECNADirect.com • sales@tecnadirect.com

4943 Driscoll Road • Warrensville Heights, OH 44146 USA
Main: 844-44-TECNA • International: +1-216-475-5629

Spot | Projection | Seam | Butt | Capacitor Discharge
Resistance / MIG / TIG / Plasma Automation & Robotics
Consumables | Accessories | Engineering | Service

DISTRIBUTED BY:



90026-00-18-10